



MAGICBOWL FIREFX® LIGHT INSTRUCTIONS ADDENDUM

The MagicBowl FireFX® light is now compatible with IntelliBrite® light colors and shows and ships default set out of the box to IntelliBrite® mode to synchronize with IntelliBrite® lights. First switch power on to the light; the previously selected color is displayed. To select a color show mode (1-7) or fixed color (8-12), turn the wall switch Off and On a specific number of times. Each number (1-17) shown below corresponds to the number of times to power-cycle the switch to activate a color light show or fixed color.

Number of times to cycle power (1-17)

- 1 **SAM Mode:** Cycles through white, magenta, blue and green colors (emulates the Pentair SAM® color changing light).
- 2 **Party Mode:** Rapid color changing building energy and excitement.
- 3 **Romance Mode:** Slow color transitions creating a mesmerizing and calming effect.
- 4 **Caribbean Mode:** Transitions between a variety of blues and greens.
- 5 **American Mode:** Patriotic red, white and blue transition.
- 6 **California Sunset Mode:** Dramatic transitions of orange, red and magenta tones.
- 7 **Royal Mode:** Richer, deeper color tones.
- 8 **Blue:** Fixed color.
- 9 **Green:** Fixed color.
- 10 **Red:** Fixed color.
- 11 **White:** Fixed color.
- 12 **Magenta:** Fixed color.
- 13 **Hold:** Save the current color effect during a color light show.
- 14 **Recall:** Activate the last saved color effect.
- 15 **Fire FX Mode:** Flickering fire effect.
- 17 **IntelliBrite Mode**

To select **FireFX® Mode:** Turn the power switch on and then cycle power, off and on, fifteen (15) consecutive times. During the off/on switching process, no illumination will occur, and then the light will begin flickering like fire. While in FireFX® mode, the light will ignore all other IntelliBrite commands to change color or mode and will remain in FireFX® mode unless put into IntelliBrite® mode.

To select **IntelliBrite® Mode:** Turn the power switch on and then cycle power, off and on, seventeen (17) consecutive times. During the off/on switching process, no illumination will occur, then a white light will illuminate. To change colors or mode follow the instructions on the top of the page.

NOTE: If this light is installed with one of the resin colored bowls, IntelliBrite mode or solid colors do not display well through the bowl and may look different than your pool light. Resin colored bowls are meant to be used with the light set to FireFX® mode.

(See back for replacement part list)

REPLACEMENT PART LIST

(Exclusive to Glass MagicBowl)

P/N 590233	MAGICBOWL WATER SPOUT, CLEAR MOLDED REPLACEMENT
P/N 590242	MAGICBOWL GASKET KIT, CLEAR UPPER & LOWER REPLACEMENT
P/N 590245	MAGICBOWL BULKHEAD AND NUT KIT REPLACEMENT, CLEAR
P/N 590238	MAGICBOWL 1/2IN CLEAR SPACER
P/N 580065	MAGICBOWL, 100' LED LIGHT ENGINE REPLACEMENT
P/N 580066	MAGICBOWL, 150' LED LIGHT ENGINE REPLACEMENT
P/N 590246	SCUPPER, ROUND BOWL, GLASS