


## CENTRIFUGAL PUMPS



# REPAIR KITS AND PARTS GUIDE

pentair.com/myers


#### **TABLE OF CONTENTS**

SERIES	DESCRIPTION	PAGE NO.
TWO STAGE PUMPS		
I2C	Lower Mechanical Seal Repair Kit (FM1)	3
2C	. Lower Mechanical Seal Repair Kit (FM1)	4
CENTRI-THRIFT PUMPS		
M, B	. Lower Mechanical Seal Repair Kit (FM1)	5
	Notes Pages	6
	Warranty	8

READY TO ORDER YOUR KIT?

SCAN THIS CODE TO LOCATE
YOUR NEAREST MYERS
AUTHORIZED DISTRIBUTOR






#### PARTS INCLUDED IN MECHANICAL SEALKIT

PART NO.	PART DESCRIPTION	ОТY
1	Gasket	1
2	0-Ring	1
3	Retainer Ring	1
4	Seal	1
5	Lip Seal	1
6	Slinger	1

#### KIT SELECTION TABLE

KIT ORDERING NO.	SERIES
528813107	I2C

### MYERS 2C SERIES - LOWER MECHANICAL SEAL REPAIR KIT (FM1)




#### PARTS INCLUDED IN SEAL REPAIR KIT

PART NO.	PART DESCRIPTION	ŌТY
1	Gasket	1
2	0-Ring	1
3	Gasket Diffuser	1
4	Seal	1

#### KIT SELECTION TABLE

SERIES
2C100
2C150
2C200



#### PARTS INCLUDED IN LOWER MECH. SEALKIT

PART NO.	PART DESCRIPTION	QTY
1	Gasket	1
2	Impeller Bolt	1
3	Lock Washer	1
4	Washer Impeller Retainer	1
5	Impeller Key	1
6	Seal 7/8 Shaft Type 2 B/CA/CE	1

#### KIT SELECTION TABLE

KIT ORDERING NO.	SERIES
528813087	150M, 200M, 150B, 200B
528813097	125M, 125B

NOTES PAGE

NOTES PAGE	

#### STANDARD LIMITED WARRANTY

Pentair Myers® warrants its products against defects in material and workmanship for a period of 12 months from the date of shipment from Pentair Myers or 18 months from the manufacturing date, whichever occurs first – provided that such products are used in compliance with the requirements of the Pentair Myers catalog and technical manuals for use in pumping raw sewage, municipal wastewater or similar, abrasive-free, noncorrosive liquids.

During the warranty period and subject to the conditions set forth, Pentair Myers, at its discretion, will repair or replace to the original user, the parts that prove defective in materials and workmanship. Pentair Myers reserves the right to change or improve its products or any portions thereof without being obligated to provide such a change or improvement for prior sold and/or shipped units.

Start-up reports and electrical schematics may be required to support warranty claims. Submit at the time of start-up through the Pentair Myers website: http://forms.pentairliterature.com/startupform/startupform.asp?type=m. Warranty is effective only if Pentair Myers authorized control panels are used. All seal fail and heat sensing devices must be hooked up, functional and monitored or this warranty will be void. Pentair Myers will cover only the lower seal and labor thereof for all dual seal pumps. Under no circumstance will Pentair Myers be responsible for the cost of field labor, travel expenses, rented equipment, removal/reinstallation costs or freight expenses to and from the factory or an authorized Pentair Myers service facility.

This limited warranty will not apply: (a) to defects or malfunctions resulting from failure to properly install, operate or maintain the unit in accordance with the printed instructions provided; (b) to failures resulting from abuse, accident or negligence; (c) to normal maintenance services and parts used in connection with such service; (d) to units that are not installed in accordance with applicable local codes, ordinances and good trade practices; (e) if the unit is moved from its original installation location; (f) if unit is used for purposes other than for what it is designed and manufactured; (g) to any unit that has been repaired by anyone other than Pentair Myers or an authorized Pentair Myers service provider; (h) to any unit that has been repaired using non factory specified/OEM parts.

Warranty Exclusions: PENTAIR MYERS MAKES NO EXPRESS OR IMPLIED WARRANTIES THAT EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. PENTAIR MYERS SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE.

Liability Limitation: IN NO EVENT SHALL PENTAIR MYERS BE LIABLE OR RESPONSIBLE FOR CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES RESULTING FROM OR RELATED IN ANY MANNER TO ANY PENTAIR MYERS PRODUCT OR PARTS THEREOF. PERSONAL INJURY AND/OR PROPERTY DAMAGE MAY RESULT FROM IMPROPER INSTALLATION. PENTAIR MYERS DISCLAIMS ALL LIABILITY, INCLUDING LIABILITY UNDER THIS WARRANTY, FOR IMPROPER INSTALLATION. PENTAIR MYERS RECOMMENDS INSTALLATION BY PROFESSIONALS.

Some states do not permit some or all of the above warranty limitations or the exclusion or limitation of incidental or consequential damages and therefore such limitations may not apply to you. No warranties or representations at any time made by any representatives of Pentair Myers shall vary or expand the provision hereof.

