



Key No.	Part Description	Model and HP		
		3305P 1/2HP	3307P 3/4HP	3310P 1 HP
1	Motor	J218-577PKG	J218-590PKG	J218-596PKG
2	Pressure Gauge	TC2104	TC2104	TC2104
3	Pump Body (Back Half)	L176-47P	L176-47P	L176-47P
4	Seal & Gasket Kit *	FPP1500	FPP1500	FPP1500
5	V-Clamp Assembly	C19-54SS	C19-54SS	C19-54SS
6	Pump Body (Front Half)	L76-37P	L76-37P	L76-37P
7	Control Valve Assembly	L162-10PS	L162-10PS	L162-10PS
8	Overhaul Kit **	FPP1511	FPP1512	FPP1513
9	Pressure Switch Assembly	TC2151	TC2151	TC2151

* Includes: water slinger, seal plate O-Ring or gasket, shaft seal, diffuser pad, and diffuser O-Ring or gasket.

** Includes: Seal and Gasket Kit plus seal plate insert, impeller and diffuser.

Repair instructions are included with all repair kits.