

STRUCTURAL CH5811

DISTRIBUTOR ASSEMBLY INSTRUCTIONS USED ON DST 5665,5666,5667,5688,10848,10849


TOP MOUNT HUB AND LATERAL SYSTEM

COMPOSITE TANKS (14", 16", 18", 21", 24", 30", 36") DIAMETER TANKS

STEP 1 Exploded view of Hub Assembly.




STEP 2 Thread cap onto Hub and insert through tank opening. (Holding Hub as shown).




STEP 3

After assembly is inside the tank, rotate the assembly 90°. Hold Hub Assembly with one hand, as shown, and assemble laterals by inserting and twisting clockwise.



STEP 4

After all laterals are assembled, hold the assembly, as shown, and using universal primer and cement, bond the 1-1/2" riser tube into Hub and lateral assembly. Riser tube can now be cut to proper length to accommodate top mounted valve.



CALIFORNIA PROPOSITION 65 WARNING

A WARNING: This product contains chemicals known to the State of California to cause cancer or birth defects or other reproductive harm.

For Structural Product Warranties visit:
Structural para las garantías de los productos visite:
Pour Structural garanties produit visitez le site :



WATER QUALITY SYSTEMS

5730 NORTH GLEN PARK ROAD, MILWAUKEE, WI 53209

P: 262.238.4400 | WATERPURIFICATION.PENTAIR.COM | CUSTOMER CARE: 800.279.9404 | tech-support@pentair.com

All Pentair trademarks and logos are owned by Pentair, Inc. or its affiliates. All other registered and unregistered trademarks and logos are the property of their respective owners. Because we are continuously improving our products and services, Pentair reserves the right to change specifications without prior notice. Pentair is an equal opportunity employer.